



Quick Start Guide LD7™



Play bingo in two easy steps!

1

Enter **Log In Number** from your sales receipt, then press OK

OK

2

Touch ENTER when button flashes **red & green**

Enter

Button Functions

Enter

Press ENTER button to mark the numbers on your cards automatically and keep up with the current game

Cards

Press the CARDS button to step through all cards being played

Views

Press VIEWS button to switch between a 1, 4, or 9-card view

Menu

Press MENU to access the Main Menu with useful information and player settings

Daubers

Allows you to select the shape of your dauber

Enable Sound

Toggle game sounds on and off

No Peek Mode

Changes all numbers on cards to a ? for added game-play suspense

Manual Daub

Enables numeric keypad to be displayed during game play for manual entry of called numbers

Disable Bingo Alert

When enabled, the large Bingo Alert will NOT be displayed. Bingos will still display.

Exit Session

Press EXIT SESSION to stop game play and logout. To return to the same session, enter the Log In Number then press OK



Guía de Inicio Rápido LD7™



Juega bingo en 2 pasos fáciles

1

Imprima número de inicio de su recibo de venta, y después presiona ok

OK

2

Presiona el botón **INGRESA** cuando el botón alumbre rojo & verde

Ingresa

Funciones del botón

Ingresa

Presiona el botón **INGRESA** para marcar los números de sus cartas automáticamente y mantenerse con el juego actual

Cartas

Presiona el botón **CARTAS** para caminar a través de todas las cartas que están siendo jugadas

Ver Cartas

Presione el botón **VER CARTAS** para cambiar entre 1, 4, o 9—cartas vistas

Menú

Presiona Menú para tener acceso al menú principal con información útil y configuración de juego

Marcador

permite que usted seleccione la forma de su marcador

Habilitar sonido

Alternar los sonidos de juego encendido o apagado

Sin modo de ver

Cambia todos los números en cartas a un (?) para el suspenso agregado de la jugada de juego

Manual para marcar

Permite que el teclado numérico sea exhibido durante el juego para la entrada manual de números llamados

Desactivar Alerta de Bingo

Cuando es permitido, la Alerta de Bingo en no será expuesto. Bingos todavía estará expuesto

Salir de Sesión

Presiona Salir de Sesión para terminar el juego y cerrar sesión. Para volver a la misma sesión, ingresa el número de inicio y después presionar ok